

# latitude°

## LG Smart TV Guide


---



### The Remote

Please use the LG remote to operate the TV. Press the red on button at the top of the remote to switch on the television.

---



### No signal on screen

If there is a message on the screen displaying “No signal” or “not programmed” please check if the TV is on the correct source channel.


---



### How to check the source

Press the source button on the remote which is situated between the Netflix button and the Prime Video button.

---



### Select HDMI 1

A window will pop up on the screen with source options. Please select HDMI1.

---



### DSTV

Please ensure that the DSTV decoder displays a green light in order for it to broadcast and display on the TV. If the light is red then it is on standby. Press the on button to activate the decoder.

---

Still not working? **Dial 123** from your apartment phone for assistance.